


ENGLISH



COFFEE GRINDER

The unit is intended for grinding coffee beans, small amount of onion, garlic, vegetables and spices.

DESCRIPTION

1. Motor unit
2. Bowl for grinding dry products
3. Bowl for chopping vegetables
4. Lid
5. Cord storage

Attention!

Do not use water when processing products. Do not immerse the motor unit (1), power cord and plug into water or any other liquids. Do not wash the unit parts in a dishwashing machine.

Attention!

COFFEE GRINDER

The unit is intended for grinding coffee beans, small amount of onion, garlic, vegetables and spices.

OPERATION TIME

The maximal allowable continuous operation time is not more than 30 seconds with an obligatory break of no less than 1-2 minutes.

The bowl (2) with one knife is intended for chopping dry products: coffee beans, spices, dry herbs.

Notes: Do not put into the unit more than 70 g of products at a time. The volume of the products to process should not exceed the maximal level mark «MAX».

The bowl (3) with the double knife is intended for chopping small amount of vegetables, fruit, onion, garlic, dried fruit etc.

Notes:

SAFETY MEASURES

Read this instruction manual carefully before using the unit and keep it for the whole operation period.

Use the unit according to its intended purpose only, as it is stated in this user manual. Mishandling the unit can lead to its breakage and cause harm to the user or damage to his/her property.

Notes:

Before you start chopping, we recommend to peel fruit, remove stones, and to cut the products into cubes approximately 2x2 cm in size.

Before chopping fresh greens, remove stems of herbs.

Do not process more than 45 g of dried fruit at a time.

Volume of the products to process should not exceed the maximal level mark «MAX».

USAGE

WARNING: Before installing the bowl (2 or 3) make sure that the power plug is not inserted into the socket.

NOTES: Product should be put into the bowl before the unit is switched on.

The blocking system prevents the unit's switching on if the lid (4) is not set on the motor unit or if the unit is set improperly.

CLEANING

Attention! The knives of the bowls (2, 3) are very sharp and dangerous. Handle them very carefully!

NOTES: Do not touch the water; unplug the unit immediately, only after that you can take the unit out of the water; apply to the authorized service center for testing and repairing the unit.

NOTES: Do not leave children unattended to touch the motor unit body and the power cord during unit operation.

NOTES: This unit is not intended for usage by children under 8 years of age.

NOTES: During the operation and the breaks between operation cycles, the unit should be placed out of reach of children under 8 years of age.

NOTES: Children aged 8 and over as well as disabled persons can use this unit only under supervision of a person who is responsible for their safety, if they are given all the necessary and understandable instructions concerning the safe usage of the unit and information about danger that can be caused by its improper usage.

NOTES: For children safety reasons do not leave polyethylene bags, used as a packaging, unattended.

NOTES: Attention! Do not allow children to play with polyethylene bags or packaging film. Danger of suffocation!

NOTES: Check the power cord and plug periodically. Do not use the unit if the unit, the power plug or the power cord is damaged.

NOTES: Do not disassemble and repair the unit by yourself. If you find any damages, unplug the unit and apply to an authorized service center.

NOTES: To avoid damages, transport the unit in original package only.

NOTES: Keep the unit out of reach of children and disabled persons.

NOTES: THE UNIT IS INTENDED FOR HOUSEHOLD USE ONLY

NOTES: BEFORE USING THE UNIT

NOTES: After unit transportation or storage under cold (winter) conditions, it is necessary to keep it for at least two hours at room temperature before switching on.

NOTES: Unit operating life is 5 years

NOTES: Guarantee

NOTES: Details regarding guarantee conditions can be obtained from the dealer from whom the appliance was purchased. The bill of sale or receipt must be produced when making any claim under the terms of this guarantee.

NOTES: This product conforms to the EMC Requirements as laid down by the Council Directive 2004/108/EC and to the Low Voltage Regulation (2006/95/EC)

NOTES: CE

NOTES: TECHNICAL SPECIFICATIONS

NOTES: Power supply: 220-240 V ~ 50/60 Hz

NOTES: Maximal power consumption: 200 W

NOTES: The manufacturer preserves the right to change the specifications of the unit without a preliminary notification.

NOTES: Устройство предназначено только для бытового использования

NOTES: ПОДГОТОВКА К РАБОТЕ

NOTES: После транспортировки или хранения устройства в холодных (зимних) условиях необходимо выдержать его при комнатной температуре не менее двух часов.

NOTES: Полностью распакуйте устройство и удалите любые наклейки, мешающие работе устройства.

NOTES: Произведите осмотр внешнего вида устройства, при наличии механических повреждений не пользуйтесь устройством.

NOTES: Перед включением убедитесь в том, что напряжение электрической сети соответствует рабочему напряжению устройства.

NOTES: КОМПЛЕКТ ПОСТАВКИ

NOTES: Моторный блок – 1 шт.

NOTES: Чаша для измельчения сухих продуктов – 1 шт.

NOTES: Чаша для измельчения овощей – 1 шт.

NOTES: Крышка – 1 шт.

NOTES: Инструкция – 1 шт.

NOTES: ТЕХНИЧЕСКИЕ ХАРАКТЕРИСТИКИ

NOTES: Электропитание: 220-240 В ~ 50/60 Гц

NOTES: Максимальная потребляемая мощность: 200 Вт

NOTES: Производитель оставляет за собой право изменять характеристики устройств без предварительного уведомления

NOTES: Срок службы устройства – 5 лет

NOTES: ГАРАНТИЯ

NOTES: Гарантия предоставляется производителем на срок 5 лет со дня покупки устройства.

NOTES: Адрес: АГ-ДЕР ПРОДАКТС ГмбХ, Австрия

NOTES: Нойбургштрассе 38/7A, 1070 Вена, Австрия

NOTES: Сделано в Китае.

NOTES: Код страны: 860

NOTES: Код города: 010

NOTES: Код района: 010

NOTES: Код почты: 1070

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

NOTES: Код факса: 01/512 20 01

NOTES: Код телефона: 01/512 20 00

